

## Supplied Fixings:



7.5mm x 100mm Concrete Screws  
5mm x 50mm Woodscrews  
Grey Screw Caps (Hinged)  
Brown Wall Plugs

## Not Supplied:



Various drill bit sizes  
Silicone sealant

## Fitting Instruction

Fixings supplied within this pack suitable for solid brickwork and 7kN blockwork.  
Ensure wall is flat and level **before** fitting the canopy.

1 Drill through gallows brackets with 8mm drill bit, hold up to correct level and width and mark on the wall, ensuring brackets are level, and drill with 6mm drill bit. Secure brackets to wall with concrete screws.




2 Remove roof from the base, position base on the brackets and drill through the steel plate fixing at the rear of the canopy. Secure to the wall with Concrete Screws.



3 From underside, drill the brackets with 3mm pilot bit and screw in the wood screws



4 Position and slide roof section into position on canopy base. Ideally through brick centres, mark, drill and fix through roof upstand (mimics the lead flashing)  
**Please Note:** The roof upstand is not pre-drilled.  
Apply clear silicone sealant to reverse side of upstand prior to fixing to stop the migration of water.



5 Apply silicone sealant bead along top of roof upstand  
6 Clean down canopy if necessary – refer to cleaning and maintenance guide overleaf.