

# Flat Canopy (With Steel Arms)



## Supplied Fixings:



7.5mm x 100mm Concrete Screws  
5mm x 50mm Woodscrews  
Grey Screw Caps (Hinged)  
Brown Wall Plugs

## Not Supplied:



Various drill bit sizes  
Silicone sealant

## Fitting Instruction

Fixings supplied within this pack suitable for solid brickwork and 7kN blockwork.

Ensure wall is flat and level **before** fitting the canopy.

- 1 Remove lead-effect roof from canopy base.
- 2 Hold canopy base at desired height over door, centralise and level. Mark, drill and fix through steel arms fixing locations. (Packers may be required to ensure canopy is level against wall, not included)



6mm Drill Bit



7.5mm x 100mm Concrete Screws

- 3 Position and slide roof section into position on canopy base. Ideally through brick centres, mark, drill and fix through roof upstand (mimics the lead flashing)

**Please Note:** The roof upstand is not pre-drilled.

Apply clear silicone sealant to reverse side of upstand prior to fixing to stop the migration of water.



6mm Drill Bit



5mm x 50mm woodscrews  
Brown plugs  
Grey screw caps (hinged)

- 4 Apply silicone sealant bead along top of roof upstand
- 5 Clean down canopy if necessary – refer to cleaning and maintenance guide overleaf.